

https://touchgrid.com/

Copyright 2024

TouchGrid Pty Ltd

TABLE OF CONTENTS

1 INTRODUCTION	3
2 FEATURES	4
2.1 WHAT'S IN THE BOX	4
3 INSTALLATION	5
3.1 CABLE TIES	5
4 CHARGING	8
4.1 POWERING ON + OFF	9
4.2 STARTUP	9
5 CONFIGURATION	10
5.1 PAIRING	10
5.2.1 DEFAULT SETTINGS "Use default"	11
5.2.1 CUSTOMISATION "Yes. Let's Start"	11
6 APP MAIN MENU	12
6.1 HOME	13
6.2 DEVICE LIST AND CONNECT	14
6.2.1 DEVICE DETAILS	14
6.2.2 EDIT DEVICE ALERTS	15
6.2.3 EDIT DEVICE SETTINGS	15
6.3 HISTORY	16
6.4 FORECAST	16
6.4 APP SETTINGS	17
6.5 SUPPORT	18
6.6 WARRANTY	19
7 SPECIFICATIONS	20
8 GLOSSARY	21
8.1 THEME	21
8.2 OPERATION	21
8.3 MEASURING FLOW RATE	22
8.4 FIRMWARE UPDATE	23
8.5 DEVICE BONDING REMOVAL	24
8.6 SENSITIVITY	24
8.7 LEARN MODE	25
8.8 FACTORY RESET / REMOVE DEVICE	26
8.9 FIELD TRIAL	27
9 TROUBLESHOOTING	28

1 INTRODUCTION

If you enjoy hot-water showers, you are also consuming energy in heating up water for your showers, so every effort to shorten your shower times not only conserves precious water, but also expensive water-heating energy.

ShowerStar is a simple but effective device that conserves water and the energy used to heat the water for showers.

ShowerStar features coloured LEDS to notify you at different stages in each shower, with the result being you can consciously change your behavior to take shorter, more water and energy efficient showers.

ShowerStar provides visual feedback when:

- 1. Water flow detected
- 2. Timer started
- 3. Half-time
- 4. Full-time
- 5. Over-time

A USB rechargeable LiPo battery lasts 6-8 months before needing recharging¹.

The Timer is configurable up to 10 minutes, with a default shower time of four minutes.

The clean design enables installation with the technical know-how needed. Simply mount the ShowerStar using the included cable ties to any shower pipe or showerhead and you're ready to save water and energy!

SMALL CHANGE. BIG IMPACT


3

¹ Assuming 4 showers a day and default alert settings..

2 FEATURES



2.1 WHAT'S IN THE BOX



3 INSTALLATION

3.1 CABLE TIES


Insert a cable tie into the upper slot on the mounting cradle. Then insert the second cable tie into the lower slot.

The rounded end of the mounting cradle should point down, with the flat end facing up.

Front View



Rear View



Wrap both cable ties around the pipe, then take the pointed end and insert it into the head of the cable tie, one at a time. Ratchet both cable ties tight to ensure the mounting cradle is properly fixed and does not slide along the shower pipes.



Note

- Mount the ShowerStar 5 to 6ft./1.5-1.8m above floor level.
- If installing the ShowerStar onto the flexible pipe, do not over-tighten to avoid compressing the pipe.
- Trim off excess length off the cable ties.

Slide the unit top down into the mounting cradle. The protruded tip of the mounting cradle should slide right into the grooves along the rounded end of the body, securing the unit.



4 CHARGING

When you first receive your ShowerStar unit, it must be charged for at least 6 hours before use. Connect the USB Type-C cable to the charging port on the ShowerStar body, then connect the other end to any 5VDC phone or USB charger and plug the charger into a power supply socket.



* USB Type-A to Type-C adaptor included as accessory.

Power on the ShowerStar device (press and hold the Operation Button for 4 seconds) when you are charging, and the RGB LED indicator will light up in **red** to indicate that the unit is charging.

Once fully charged, the RGB LED indicator will light up **green**. You can then disconnect the USB Type-C charging cable, and slide it back into the mounting cradle.


The battery will typically last six to eight months, depending on configuration and frequency of showers.

4.1 POWERING ON + OFF

Press and hold the Operation Button for 4 seconds to power on. To power OFF, press and hold the Operation Button for 5 seconds. The red indicator lights up and then extinguishes.

4.2 STARTUP

On power up, the RGB LED indicators light up: RED, GREEN then BLUE and the speaker beeps.




5 CONFIGURATION

Download the App "ShowerStar" from the App Store or Google Play.

5.1 PAIRING

* Turn Bluetooth on on your mobile device settings.

Open the "ShowerStar" App on your mobile device and follow the steps below.




^{*} Step 3: Refer Section 6.4 App Settings, Page 17 for the details.

[:] You can re-configure these settings later in the App under the App Settings page..

^{*} Bluetooth RF indoor range is ~16 ft / 5 meters.


5.2.1 DEFAULT SETTINGS "Use default"







Once the setup wizard has completed the setup, you will be greeted with the Home page.

5.2.1 CUSTOMISATION "Yes. Let's Start"









6 APP MAIN MENU

The App allows customisation of timer and alert settings, firmware updates and entering of water and energy data for savings calculation.

The menu will be launched, showing navigation to additional pages.




6.1 HOME




Here, some of the key figures recorded by the ShowerStar device, such as the average and longest shower times, as well as the units of water and energy saved, are shown. The most important figure here of course is the total cost saved from using the ShowerStar!

For more information, please refer to the detailed illustrations below:



6.2 DEVICE LIST AND CONNECT



6.2.1 DEVICE DETAILS

The App allows customisation of timer and alert settings, firmware updates



Using the App settings can be edited:

- Device name
- Timer (0-10 mins)
- Theme


Disconnect

To terminate connection to the ShowerStar device, simply tap on Disconnect.

Note, doing so does not remove the paired connection to the ShowerStar device. It simply terminates the Bluetooth connection to the device.

6.2.2 EDIT DEVICE ALERTS

Using the App, the settings can be edited






Using the App these alerts can be edited:


- Warm Up Delay time (0-2mins)
- Half-time alerts (enable / disable)
- Full-time alerts (brightness / duration)
- Over-time alerts (enable / disable / brightness / duration / frequency)

*Tap the green boxes to edit the above settings.

*Make sure you save the changes.

6.2.3 EDIT DEVICE SETTINGS





Using the App these settings can be edited:


- Update firmware
- Field trial mode (enable / disable)
- Learn mode (recalibrates accelerometer to detect when shower is flowing)
- Factory reset
- Remove device
- Adjust sensitivity manually (Low / High)

*Tapthe green boxes to set the above settings.

6.3 HISTORY

The History page will be shown containing a log of all the showers recorded by the ShowerStar device.





Note:


The History page shows all your devices by their names and the respective Device ID, so you will be able to differentiate the shower logs recorded from different devices.



- Export button which allows you to export all shower logs to a CSV file, allowing you to share the log.
- Tap on CLEAR to confirm clearing all logs.

6.4 FORECAST


The Forecast page will then be shown indicating some annual savings figures.





The calculation works by getting the time difference between the Average Shower Time and the Target Shower Time implemented by the ShowerStar device.

The time difference is then multiplied with the number of showers per day, and the water flow rate to obtain the units of water saved per day. This is then multiplied with 365 to obtain the units of water saved per year. Multiply this with the water cost and the cost of water savings can be obtained.



Back to main menu

*Make sure you save the changes.

6.4 APP SETTINGS

Here, you may reconfigure the settings that you first setup in the Let's get started page.



The App requires some information from you in order to calculate usages and savings of your water and energy resources.

Set App Settings



App Settings:

Units > Select metric / imperial
City > Select the listed city or other

Type of Heating > Select the type of water heating system

- Gas storageGas instantaneousElectric storage
- Electric heat pump

Cost Configuration:

Flow Rate > Enter the Flow Rate measured on your shower

system.

Select FAQ "where do I find the flow rate?" for more information on measuring your water flow rate on your shower system.


- *Water Cost > The cost of one unit of water.
- *Inlet Water Temperature > The water temperature at the inlet pipe.

Desired Shower Temperature > Shower water temperature *Power Cost > The cost of one unit of power.

- * Automatically populated once you have selected the City and Type of Heating fields.

6.5 SUPPORT


Tap on the Support tab on the side menu to access documentations and some Frequently Asked Questions for the ShowerStar device.



Tap on the Expand icon "+" next to the question to expand the explanation section.

6.6 WARRANTY

To activate your warranty, tap on the Warranty tab in the App and fill up the Warranty Registration form. You may refer to the following table to help fill up the form:



USER MANUAL SHOWERSTAR

SPECIFICATIONS

FEATURES





1000mAh 3.7V Lipo Battery

Recharge every ~8-12 months* *Assumes 4 showers / day and subject

to alert configuration

5VDC USB Charger

Bluetooth Low Energy ™ Communications App OS Support iOS™ + Android ™

Estimated Product Life 8-10 years

PHYSICAL

Charging

32° to 113° F | 0° to 45° C 14° to 140° F | -10° to 60° C Operating Temp Storage Temp

IP Rating

3.27" x 1.8" x 0.9" $L \times W \times H$ 83mm x 45mm x 23mm

Weight 2.3 ounces | 65 grams



WARRANTY

1-year limited warranty

APPROVALS

FCC (US and Canada) Part 15.247 and RSS 247 CE - EMC (EN/IEC 661010-1, and EN IEC61326) RED ETSI EN 310 489-1, EN 301 489-17, ETSI EN 300 328, EN IEC 62311:

RCM, RoHS, Prop65

Battery (UL1642, UL2054, IEC62133, CB, CE, RoHs, UN38.3, REACH)

FOR INDOOR USE ONLY.

WATER RESISTANT, DO NOT IMMERSE FULLY IN WATER.

ORDERING

TC168 ShowerStar Shower Sensor Timer

LEGAL

© 2024 TouchGrid Pty Ltd. All rights reserved. Designed in Australia. Made in Malaysia.

© 2024 TouchGrid Pty Ltd. All rights reserved. TouchGrid and ShowerStar are registered trademarks of TouchGrid Pty Ltd. All other trademarks are the property of their respective owners. Patents Pending.

8 GLOSSARY

8.1 THEME

Once installed and configured you can begin saving water and energy as you actively shorten your showers.

The following table shows the difference between the 3 operating themes of the ShowerStar device:

Theme	Water Flow	Timer Start	Half Time (Optional)	Full Time	Over-Time (Optional)
Simple					
Trafic Light					
Flashy					

8.2 OPERATION

Charging	Fully Charged	Low Battery	Power On	Power Off
	0	000		

8.3 MEASURING FLOW RATE



Step 1: Turn on the shower head

Turn on the shower head to be tested and adjust the flow to how you normally use it.

Step 2: Hold the SHOWER FLOW MEASUREMENT BAG

Hold the SHOWER FLOW MEASUREMENT BAG supplied with the product open and place it under the fixture for exactly FIVE (5) seconds. Make sure to capture all of the water coming out of the shower head.


Step 3: Remove the bag from the flow

Remove the bag from the flow. Holding the bag open, raise to eye level and read the flow rate measurement. Repeat to check the result. Input the flow rate value to the TouchGrid ShowerStar App.

Tip:


If your showerhead is too wide for this flow rate bag, use the same procedure but collect the water in a bucket and afterwards pour the collected water into the measurement bag to determine the flow rate.

8.4 FIRMWARE UPDATE



8.5 DEVICE BONDING REMOVAL


Remove device bonding to you mobile.



8.6 SENSITIVITY

There is also a 15-step sensitivity slider that controls how sensitive the ShowerStar device is at detecting the start of your showers.

As this is different for differing shower systems, you should experiment with the sensitivity setting to accurately capture the start of your showers.




 $[^]st$ Set the sensitivity lower if the device false triggering (blue flashing if no water running).


8.7 LEARN MODE

Tap on Learn Mode to allow your ShowerStar device to calibrate its sensors to accurately detect the start of your showers.

The Start Calibration window will then be shown. Slide the ShowerStar device to its mounting cradle, run your shower, and tap on START.




8.8 FACTORY RESET / REMOVE DEVICE



8.9 FIELD TRIAL

The Field Trial Mode is a special operating mode designed to assist utility companies to determine the effectiveness of the ShowerStar device.

Tap on the toggle to enable or disable the Field Trial Mode for the device.



9 TROUBLESHOOTING

9.1 False timer starts / Blue flashing but no water is running.
Adjust the sensitivity from high to low and monitor again.
Refer to page 24, section 8.6.

9.2 Flushing toilet / Turn On tap water, Blue is flashing Adjust the sensitivity from high to low and monitor again. Refer to page 24, section 8.6.

9.3 Cannot connect to my phone after forget the device on mobile phone.Remove the bonding on your device.Refer to page 24, section 8.5.

9.4 Phone charger with USB Type A Port.Use Type A to Type C adapter, included as accessory.Refer to page 4, section 2.1.